

PLASTIC TOUCHLESS FAUCET HANDLE CONVERTER INSTALLATION & OPERATION

On this card you'll find instructions for installing and operating the *Plastic Touchless Faucet Handle Converter* for BUNN servers equipped with pull down "pedal" faucet handles and standard pull down "Tomlinson" faucet handles.

Installation & Operation

Note: Prior to installation of the touchless faucet adaptor, it is important to clean the faucet assembly to ensure proper functionality. Refer to the *Coffee & Tea Dispenser Faucet Cleaning & Sanitizing* instructions.



1 Remove the entire upper faucet assembly by unscrewing (counterclockwise) the bonnet from the lower faucet assembly



2 Using your thumb, depress the seat-cup and spring. Slide off existing handle.



3 With the seat-cup and spring still depressed, slide touchless handle onto faucet handle stem. Release seat-cup and spring.



4 Reattach the upper faucet assembly by screwing (clockwise) the bonnet onto the lower faucet assembly



5 **Using the cup**, push the faucet adaptor forward to dispense.



To avoid the risk of burns, **DO NOT** use your hand to engage the faucet adaptor.

Cleaning – During regular cleaning of the faucet assembly, the adaptor should be removed as well for cleaning. Clean with a mild detergent and hot water. Allow to air dry.