



BUNN® LOW PROFILE AXIOM® BREWER & THERMAL SERVER EQUIPMENT CARD

On this card you'll find instructions for operating, cleaning and troubleshooting minor problems with your coffee brewer plus product hold time standards and water filter ordering information.

Brewer Specifications

Brand:	 Starbucks Coffee®	 Seattle's Best Coffee®
Portion Size:	2.5 oz	2 oz
Coffee Yield:	1.9L	1.9L
Server Type:	1.9 Liter Carafe, Low Profile	
Brew Basket:	Black Plastic	
Filter Size:	9" x 4" (CF12)	
Filter #s	SKU# 12420611, SUPC# 3604394	



Instructions

1 Pre-heat airpot(s) with hot water.



2 Place one filter into the brew basket



3 Pour the entire portion pack into the brew basket. Shake to level.



4 Slide the brew basket into the rails of the brewer until it stops.



5 Place an empty server under the brew basket.



6 Make sure the server is pre-heated, remove the lid and place server under brew basket.



7 Do not remove the server until the coffee has stopped dripping, then replace lid to retain heat.

Brewer and Server Cleaning

Daily

- Rinse brew basket and airpot with hot water after each brew cycle.
- Wipe around spray head of brewer daily. Do not use soap or abrasives.
- Wipe exterior of brewer daily. Do not use abrasives.

Weekly

1. Use Urnex® cleaner or similar cleaner once a week in all airpots and brew baskets.
2. Pour ½ contents of package into airpot.
3. Add hot water and soak for 15 minutes.
4. Drain and rinse thoroughly.

Note -

In areas with scale (white around spray head hole and hot water spigot) use the cleaning tool provided with the brewer to clean around the spray head. If you do not have a cleaning tool, contact Bunn or your Nestlé Coffee Partners representative.



Brewed Coffee Hold-Time Standard

2 hours - When using pre-heated airpots.

Tip - Set a timer or write (with an erasable marker) the time the coffee was brewed on the back of the server so you know when to discard the brewed coffee.

Brewer & Server Troubleshooting Guide

PROBLEM	POSSIBLE CAUSE	SOLUTIONS
Brew cycle will not start	No power to brewer	Make sure unit is plugged in
	No water to brewer	Make sure shut-off valve is open
Weak coffee	Improper dose	Make sure you are using recommended dosage
	Check for missing spray head	Replace missing sprayhead
Brew basket overflows	Wrong dose	Make sure proper dose of coffee is used
	Wrong paper filter	Get correct paper filter
Coffee is cold	Coffee remained in airpot more than 2 hours	Use coffee within 2 hours
Server overflowing	Server not empty	Make sure server is empty

Note — Ordering, changing and cost of water filtration is the customers responsibility.

To order water filters log into the Customer Portal at <https://www.nestlecoffeepartnerssl.com>. For directions on how to change filters, go to the Training section of the Customer Portal.